

# Combination Lock Instructions

**1.** There are 3 digits for this lock along with 1000 combinations.

**2.** The lock is set by default in the factory using “000” as code.

**3.** How to reset the password:

When the lock is in the open position, insert a pin with 0.08” (2mm) diameter into the tiny round hole on the lock, and reset the new password by turning the dial. Please keep the new password, because once you forget it, it can't be opened.

